

GONEO EV CHARGING

User Manual



VER2.15

Index

- 01** Download
- 02** Quick guide
- 03** Charging
- 04** Main page
- 05** Add Charger
- 06** Charger menu
- 07** Scan QR code
- 08** Charger status
- 09** User management
- 10** Appointment charging
- 11** charging statistics page
- 12** Notification
- 13** Charger setting page
- 14** User account page
- 15** RFID card management
- 16** Configuration WLAN via Bluetooth

01 Download



Use phone's camera or browser to scan the corresponding QR code to download the APP.
Or search in Google Play、App Store.


02 Quick guide

Start App

Register

Scan the QR-code

Working





03 Charging


Plug the connector

Set current


Start charging



04 Main Page



05 Add charger




Add charger

Click blank for return main page

Select charger

06 Charger menu



Share

Share QR code

History

Orders


Users

User management


Settings

Charger setting


07 Scan QR code




08 Charger status




Plug Charger




Tap to charge




Charging



Charging finish




Reserved



Fault


09 User management




Remove user account:

1. Slide left
2. Tap to delete
3. Confirm to delete

10 Appointment charging




Single charging appointment




Repeat charging appointment


11 Charging statistics page



12 Notifications



13 Charger setting page




Enable the charging button or not

Rename charger

Remove charger

14 User account page




System setting:

- Language setting
- System Theme



Match RFID card


15 RFID card management



Add card

Slide left to display delete button

16 Configuration WLAN via Bluetooth



1. Turn on your phone's Bluetooth.

1. Tap the "WLAN Config Mode" button and the APP will connect to the charging pile via Bluetooth automatically.

2. You are required to authorize positioning permission when the application asks for it.

3. Wait for the Bluetooth connection to succeed.

4. Fill your home's WIFI SSID and password, and submit.